

A1501 PRO-3 PROFESSIONAL VACUUM CLEANER



Gruppo di appartenenza	Suction facility for suction of dust and small debris. The equipment cannot be used to suck up liquids.
Essential features	⇒ One-stage, high speed and high power motor ⇒ Three filtering stage: paper bag, nylon bag and long-lasting polysterene filtering cartridge. ⇒ Suction group protected by a a plastic housing; stainless steel structure ⇒ Wheel-equipped, easy to move ⇒ Possibility to connect two units at the same time ⇒ Universal hose adapter for easy connection
Units which can be served by the suction unit	Dry model trimmer, finishing instrument, stump separating unit, sandblaster, working bench
Connection pipe	Ø 36x30 – 3m length
Filtering degree	1μ
Motor power	1000W
Suction volume	150m ³ /h
Noise level	<69 dB (A)
Line tension	230v A.C. 50 Hz (different tensions on request)
Length	380 mm
Width	380 mm
Height	620 mm
Net weight	9,8 Kg