

AP0-46 OROCOR



Product group	Abrasives for roughing out
Product	Corundum in grains
Colour	White
Grain size	Grain 46
Conversion in micron	350µ approx.
Chemical composition	Al_2O_3 95,0% SiO_2 0,4% FeO_3 0,2% TiO_2 3,5% CaO 0,25% Cr_2O_3 0,01%
Main features	⇒ Hardness, sharp effect, renewing cutting edge and high resistance to wear ⇒ Most suitable to remove investment and casting oxidations on non-precious alloys for ceramic
Recommended sandblaster	Sandblaster for roughing out with abrasive recycle
Aspect of the surface after the treatment	The metal surface after the treatment, if carried out at the correct pressure, is clean, clear and homogeneously rough. ATTENTION: the roughness on the surface is originated by the material raised when the abrasive grain hits and penetrates in depth according to the pressure used.
Working Pressure	4 – 5 BAR (60 - 70 PSI)
Recommended nozzle	Ø 3,0 mm
Sales package	Plastic Can à Kg 5 (code AP-046) Sack à Kg 25 (code AP046S)