

AP-090 MICROBLAST



Product group	Glassbeads for satin-finishing
Product	Glassbeads
Colour	Transparent white
Grain size	N. A.
Conversion in micron	90µ appr.
Chemical composition	SiO₂ 70 - 73% Na₂O + K₂O 13 - 15% CaO 8 - 12% MgO 3 - 5% Al₂O₃ 0,5 - 2% Pb 0,01%
Main features	⇒ Globe-shaped ⇒ Suitable to polish the surfaces of all metals ⇒ No material is removed – roughness peaks are compressed thus increasing the molecular compactness
Machine to be used	Finishing microblaster without abrasive recycle
Aspect of the surface after the treatment	After the treatment, the metal surface is smooth, polished and with no roughness. ATTENTION: the smaller the glassbeads are, the smoother and more satined the surface will be
Precautions	None
Working pressure	2 - 4 BAR (30 - 60 PSI)
Recommended nozzle	Ø 0,8 mm for utmost precision; Ø 1,5 mm for higher speed
Sales package	Plastic can à Kg 5 (code AP-090) Sack à Kg 6 (code AP090S)