

A5103S MODEL TRIMMER MT-WET AL



Product group

Electric tools used in grinding, cutting or polishing operations

Main features

- ⇒ Excellent quality-price ratio
- ⇒ Stable, sturdy and easy-to-use
- ⇒ 12mm aluminium backing pad
- ⇒ Front tilted by 10 degrees for improved ergonomics
- ⇒ Working plan fitted with guidelines
- ⇒ Electromagnetic safety switch preventing the machine from starting up accidentally after a voltage drop
- ⇒ Solenoid valve on the water feeding and flow rate reducer
- ⇒ Abrasive disc in dual cloth reinforced carborundum and bakelite bond
- ⇒ Protective casing of the rotating part molded in sturdy ABS, easy to remove for cleaning

Size of the abrasive disc

Ø 250 mm with Ø 25.4 mm hole

Standard abrasive disc

Traditional coarse grain reinforced carborundum with bakelite bond and dual cloth according to FEPA regulations

Optional abrasive disc

Extremely long lasting with artificial diamond-coated abrasive surface

Motorization

Alternate current induction motor

Motor voltage

230v AC

Speed of rotation

2800 rpm

Motor power

1100W

Line voltage

230v AC 50/60 Hz

Width

320 mm

Depth

480 mm

Height

360 mm

Net weight

16,4 Kg

Gross weight

18.6 Kg